



Applications



Wire Fencing



Vineyard Trellising



Fruit Growing

Design and Performance

Load Rating


DPAK 4 (4 mm 5/32 in)	DPAK 6 (6 mm 1/4 in)	DPAK 8 (8 mm 5/16 in)
750 kg 1650 lbs	1750 kg 3860 lbs	2800 kg 6170 lbs

Material


- Dynamic housing: zinc-aluminium alloy - ZA
- Dynamic roller: ceramic (Sintox)
- Dynamic spring: stainless steel
- Wire rope: zinc-aluminium Zn-AL coated

Kit Contents

- Dynamic 4, 6 or 8
- Fused wire rope
- Release key



Dimensions and Weights



	Dynamic 4	Dynamic 6	Dynamic 8
A Length	49 mm 1.9 in	62 mm 2.4 in	68 mm 2.6 in
B Height	42 mm 1.6 in	42 mm 1.6 in	52 mm 2.0 in
C Depth	15 mm 0.5 in	15 mm 0.5 in	18 mm 0.7 in

Packaging

	DPAK 4	DPAK 6	DPAK 8
4 m 13 ft Wire Length			
Item Weight	0.54 kg 1.19 lbs	0.83 kg 1.82 lbs	-
Box Quantity	4	4	-
Box Weight	2.16 kg 4.70 lbs	3.30 kg 7.27 lbs	-
5 m 16 ft Wire Length			
Item Weight	-	0.96 kg 2.11 lbs	-
Box Quantity	-	4	-
Box Weight	-	3.80 kg 8.30 lbs	-
6 m 20 ft Wire Length			
Item Weight	-	1.18 kg 2.20 lbs	-
Box Quantity	-	4	-
Box Weight	-	4.72 kg 10.36 lbs	-
7 m 23 ft Wire Length			
Item Weight	-	1.23 kg 2.70 lbs	-
Box Quantity	-	4	-
Box Weight	-	4.92 kg 10.84 lbs	-
8 m 26 ft Wire Length			
Item Weight	-	1.37 kg 3.02 lbs	2.32 kg 5.11 lbs
Box Quantity	-	4	2
Box Weight	-	5.48 kg 12.08 lbs	4.64 kg 10.23 lbs


Installation - Trellising

1




Loop sling around an end fixing point.

2



Feed through a fixed anchor point and through one channel of the Dynamic wire joiner.

3



Run wire around a second end fixing point and back through the free channel of the Dynamic wire joiner.

4




Tension as necessary using the appropriate tensioning tool (DPAK 8 requires XL tensioning tool).

5




Installation - Fencing

1




Loop the wire sling around the bottom of the strainer post using a staple to secure if required.

2



Feed the wire through the Dynamic wire joiner and around the second end post using a staple to secure.

3



Tension as necessary using the appropriate tensioning tool (DPAK 8 requires XL tensioning tool).

4



The installation is now complete.

5

